

Directions for using Crystal Applicator Tool and Button Die Sets (Items B1401, B1701)
 Designed for use with Swarovski ELEMENTS Buttons as listed below.
Please read directions carefully before operating the tool.

Refer to Fig. 1

1. Identify (A) upper and (B) lower die holders on tool
2. Ensure tool handles can be opened completely.
- If necessary, adjust with (C) stroke adjustment screw.
3. Pierce hole in material for button location if material thickness required. (If replacing existing buttons this will not be necessary.)

Refer to Fig. 2

4. Attach upper and lower dies in die holders.
5. Place button in upper die with shank pointing downward.
6. Close the tool gently to ensure the button is positioned correctly in the upper die.
7. Place nail in lower die.
8. Position material over nail point.


When handling the material, be careful not to change location of the nail.

Button will not engage if the nail is not perfectly straight.

9. Squeeze handles until button and nail are securely attached to material.

(This may require the use of both hands.)

10. Release the tool and remove button and material from upper die.



B1401, B1701 Button Dies can be used with these Swarovski Buttons*	
B1401 14 mm Buttons	B1701 17 mm Buttons
1790/100	1790/104
1790/1134	1790/140
	1791/120
	1796/140

*Please Note: Style 1793/160 cannot be applied with these dies.